



## **BIBER** **22** **BÜRSTE**

### Wechseln des Bürstenaufsatzes der BIBER 22 BÜRSTE

- Stellen Sie sicher, dass vor dem Wechsel des Bürstenaufsatzes die Stromversorgung getrennt wird.
- Verwenden Sie für den Wechsel des Bürstenaufsatzes dem im Lieferumfang enthaltenen Bürstenausheber (1).
- Setzen Sie den Bürstenausheber an der Kerbe (2), die mit dem Pfeil (3) gekennzeichnet ist, an und hebeln Sie die Bürste mit dem Bürstenausheber nach oben (4).
- Ziehen Sie den Bürstenaufsatz vom Antriebszapfen des Bürstenkopfes ab.
- Zum Einbau des Bürstenaufsatzes einfach den Bürstenaufsatz auf der Nabe ansetzen und bis zum Einrasten fest aufdrücken (5)



# rössle


Technik für saubere Teiche

# INSTRUCTIONS FOR CHANGING BRUSHES

## **BIBER** **22** **BÜRSTE**

### Changing the brush attachments of the BIBER 22 BRUSH

- Make sure that the power supply is disconnected before changing the brush attachment.
- Use the brush lifter (1) included in the scope of delivery to change the brush attachment.
- Place the brush lifter on the notch (2) marked with the arrow (3) and lever the brush upwards with the brush lifter (4).
- Pull the brush attachment off the drive pin of the brush head.
- To install the brush attachment, simply place the brush attachment on the hub and press firmly until it engages (5)



**rössle**

Technology for clean ponds