



# INSTRUCTIONS FOR CHANGING BRUSHES

## **BIBER** **22** **BÜRSTE**

### Changing the brush attachments of the BIBER 22 BRUSH

- Make sure that the power supply is disconnected before changing the brush attachment.
- Use the brush lifter (1) included in the scope of delivery to change the brush attachment.
- Place the brush lifter on the notch (2) marked with the arrow (3) and lever the brush upwards with the brush lifter (4).
- Pull the brush attachment off the drive pin of the brush head.
- To install the brush attachment, simply place the brush attachment on the hub and press firmly until it engages (5)



**rössle**

Technology for clean ponds