

BISAM **44** **BÜRSTE**

Wechseln des Bürstenaufsatzes der BISAM 44 BÜRSTE

- Stellen Sie sicher, dass vor dem Wechsel des Bürstenaufsatzes die Stromversorgung getrennt wird.
- Für den Wechsel des Bürstenaufsatzes ist kein Werkzeug notwendig.
- Drücken Sie die Walzenbürste in Richtung des Getriebes (Schritt 1) und ziehen Sie den Bürstenaufsatz auf der anderen Seite nach Außen (Schritt 2).
- Beim Einbau setzen Sie den Walzenbürste auf die Getriebebenabe und drücken den Bürstenaufsatz auf der anderen Seite in Position, bis er einrastet.



rössle

Technik für saubere Teiche

INSTRUCTIONS FOR CHANGING BRUSHES

BISAM **44** **BÜRSTE**

Changing the brush attachments of the BISAM 44 BRUSH

- Make sure that the power supply is disconnected before changing the brush attachment.
- No tools are needed to change the brush attachment.
- Push the roller brush towards the gearbox (step 1) and pull the brush attachment outwards on the other side (step 2).
- When mounting, place the roller brush on the gear hub and push the brush attachment on the other side into position until it engages.



rössle

Technology for clean ponds